

MEMBRANE SILL PAN WITH BACK DAM. USE MOLDING TO

-3CM (1 $\frac{1}{4}$ ") STONE SILL EXTENSION SET IN SLOPED MOTAR. BOND OUT FROST WALL AT DOORS ONLY, OR USE THIS HEIGHT FOR ALL WALLS AND SCREED